

## Cromar Dry Fix Slate Verge

### Data

The Cromar dry fix slate verge is the perfect solution for mortar free slate verges and provides an all weather solution.

Covering the ends of slating battens to provide a traditional appearance, It is designed to fit most natural and manmade slate up to 6mm in thickness and completely eliminates all the long-term problems associated with traditional pointing methods.

### Advantages

- BS8612 compliant
- Easy to handle 2m lengths.
- Quicker to fit than traditional methods
- Improved design for enhanced appearance
- Pre-fitted expansion joints
- Enables thermal movement
- Self-draining
- Protects against wind uplift
- Weatherproof and maintenance free
- Can be fitted in inclement conditions
- No special tools or skills required

### Product codes:

Slate verge : R/SLATEVERGE

Slate verge connector : R/SLATEVERGE/CON

## Installation Guide

1, When installing ensure the battens are left flush with the outer brickwork/arge board.



2, Install the Cromar Dry Fix Slate Verge directly on top of the battens allowing for a 50mm overhang at the eaves into the gutter and so not to obstruct the gutter the end of the Slate verge may need trimming underneath.



3, If the verge is more than 2 metre in length it is essential that a Cromar Slate Verge connector is used to join the two pieces and we recommend a small bead of clear waterproof sealant to the joint.



4, Once all the slate verge is installed start laying the slates ensuring that they are fixed into the overlap of the verge unit.



